

UNCLASSIFIED

AD NUMBER
ADB178696
NEW LIMITATION CHANGE
TO Approved for public release, distribution unlimited
FROM Distribution authorized to DoD only; Specific Authority; 31 JUL 1993. Other requests shall be referred to Army Medical Research and Development Command, Fort Detrick, MD 21702-5012.
AUTHORITY
USAMRDC ltr 3 Apr 1996

THIS PAGE IS UNCLASSIFIED

**SUPPLEMENTARY**

**INFORMATION**



DEPARTMENT OF THE ARMY  
U.S. ARMY MEDICAL RESEARCH AND MATERIEL COMMAND  
FORT DETRICK, FREDERICK, MD 21702-5012

REPLY TO  
ATTENTION OF:

MCMR-RMI-S (70-1y)

ERRATA  
AD-B178696<sup>3</sup> Apr 96

MEMORANDUM FOR Administrator, Defense Technical Information  
Center, ATTN: DTIC-OCP, Fort Belvoir,  
VA 22060-6218

SUBJECT: Request Change in Distribution Statement

1. The U.S. Army Medical Research and Materiel Command has reexamined the need for the limited distribution statement on technical report written for Contract Number DAMD17-90-C-0078. Request the limited distribution statement for Accession Document Number ADB178696 be changed to "Approved for public release; distribution unlimited." A copy of this report should be released to the National Technical Information Service.

2. Point of contact for this request is Mrs. Judy Pawlus at DSN 343-7322.

ERRATA  
AD-B178696

*Gary R. Gilbert*  
GARY R. GILBERT  
COL, MS  
Deputy Chief of Staff  
for Information Management

AD-B178 696



AD \_\_\_\_\_

CONTRACT NO: DAMD17-90-C-0078

TITLE: DEVELOPMENT OF NEW LASER PROTECTIVE DYES

PRINCIPAL INVESTIGATOR: Dennis P. Pacheco, Ph.D.

CONTRACTING ORGANIZATION: Spectra Science Corporation  
300 Metro Center Blvd.  
Warwick, Rhode Island 02886

REPORT DATE: July 31, 1993

TYPE OF REPORT: Phase II Final Report

PREPARED FOR: U.S. ARMY MEDICAL RESEARCH AND DEVELOPMENT COMMAND  
Fort Detrick, Frederick, Maryland 21702-5012

DISTRIBUTION STATEMENT: Distribution authorized to DOD Components only, Specific Authority, July 31, 1993. Other requests shall be referred to the Commander, U.S. Army Medical Research and Development Command, ATTN: SGRD-RMI-S, Fort Detrick, Frederick, MD 21702-5012.

The views, opinions and/or findings contained in this report are those of the author(s) and should not be construed as an official Department of the Army position, policy or decision unless so designated by other documentation.

94-02075



94 1 24 074

②L  
DTIC  
ELECTE  
JAN 25 1994  
S C D

# REPORT DOCUMENTATION PAGE

Form Approved  
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503

1. AGENCY USE ONLY (Leave blank)		2. REPORT DATE 31 July 1993	3. REPORT TYPE AND DATES COVERED Phase II Final (8/1/91-7/31/93)	
4. TITLE AND SUBTITLE Development of New Laser Protective Dyes			5. FUNDING NUMBERS Contract No. DAMD17-90-C-0078  65502A 3P665502M802.CA.249 WUDA335459	
6. AUTHOR(S)  Dennis P. Pacheco, Ph.D.				
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)  Spectra Science Corporation 300 Metro Center Blvd. Warwick, Rhode Island 02886			8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES) U.S. Army Medical Research & Development Command Fort Detrick Frederick, Maryland 21702-5012			10. SPONSORING / MONITORING AGENCY REPORT NUMBER	
11. SUPPLEMENTARY NOTES  SBIR 90.1.II (A90-192), Phase II				
12a. DISTRIBUTION / AVAILABILITY STATEMENT Distribution authorized to DOD Components only, Specific Authority, July 31, 1993.			12b. DISTRIBUTION CODE	
13. ABSTRACT (Maximum 200 words)  The overall purpose of this research effort was to develop dyes that are compatible with optical grade plastic that can be manufactured into lens devices, and will provide protection for the eye against lasers that emit in the region from 700 nm to 1100 nm.  In Phase II, a number of new laser-protective dyes were synthesized and tested in optical plastics. These dyes were drawn from five different chemical families: squarates, croconates, fluorenes, methines, and metal-complex dyes. Also, methods of thermally and photochemically stabilizing these dyes have been investigated and developed. The basic strategy of the program is shown schematically on page 3 of report. Sets of lenses from several dyes or dye systems have been produced and will be delivered to the contractor for evaluation.				
14. SUBJECT TERMS RA III; SBIR; Phase II; Laser; Laser Hazards; Laser Dye Synthesis; Ocular Protection; Ocular Hazard			15. NUMBER OF PAGES	
			16. PRICE CODE	
17. SECURITY CLASSIFICATION OF REPORT  Unclassified	18. SECURITY CLASSIFICATION OF THIS PAGE  Unclassified	19. SECURITY CLASSIFICATION OF ABSTRACT  Unclassified	20. LIMITATION OF ABSTRACT  Limited	

## SECTION I - INTRODUCTION

The overall purpose of this research effort was to develop dyes that:

- are compatible with optical grade plastic that can be manufactured into lens devices and
- will provide protection for the eye against lasers that emit in the region from 700 nm to 1100 nm.

One of the major problems with dyes available for this purpose is that they are thermally and/or photochemically unstable. In Spectra Science's Phase I research, the feasibility of thermally stabilizing cyanine and squarylium dyes for simulated polycarbonate injection-molding conditions was demonstrated, justifying the continuation of Spectra Science's dye synthesis and evaluation program. In Phase II, a number of new laser-protective dyes were synthesized and tested in optical plastics. These dyes were drawn from five different chemical families: squarates, croconates, fluorenes, methines, and metal-complex dyes. Also, methods of thermally and photochemically stabilizing these dyes have been investigated and developed. The basic strategy of the program is shown schematically on the following page. Sets of lenses from several dyes or dye systems have been produced and will be delivered to the contractor for evaluation.


## SECTION II - PROGRAM HIGHLIGHTS

### A. DYES SYNTHESIZED DURING THE PROGRAM

Table 1 lists the dyes that have been synthesized during this program with  $\lambda_{max}$  greater than 700 nm. The structures of these dyes are shown in Figure 1. Because of the sheer number of these compounds, we will not attempt to discuss the synthetic routes here. The individual monthly reports can be consulted for details.

DTIC QUALITY INSPECTED 8

ion For	
CRA&I	<input type="checkbox"/>
TAB	<input checked="" type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution	
Availability Codes	
Dist	Availability or Special
E-4	



**Table 1**

Dyes with Absorption Maxima ( $\lambda_{\max}$ ) Greater than 700 nm  
Synthesized by Spectra Science During this Program

<u>Dye</u>	<u>Dye Classification</u>	<u><math>\lambda_{\max}</math> (nm)<sup>(1)</sup></u>
1044	Croconium	823
1045	Squarylium	765
1049	Squarylium	1057
1096	Squarylium	742
1097	Squarylium	733
1098	Squarylium	912 (DMF)
1099	Croconium	846 (DMSO)
1100	Squarylium	988 (TECE)
1101	Squarylium	905 (TECE)
1106	Squarylium	711
1107	Squarylium	1150 (TECE)
1109	Squaramide	835 (DMF)
1112	Squarylium	1010/1115/1100 (TECE)
1115	Squarylium	910 (TECE)
1116	Squarylium	905/1075
1117	Squarylium	870/965/1140
1118	Squarylium	980
1119	Squarylium	606/650/852 (TECE)
1120	Squarylium	725 (TECE)
1122	Squarylium	1038 (TECE/MeOH)
1123	Squarylium	952 (TECE/MeOH)
1124	Squarylium	950 (TECE/MeOH)
1125	Squarylium	950 (TECE)
1126	Squarylium	1015 (TECE)
1127	Squarylium	1000
1128	Squarylium	820
1129	Squarylium	1000 (TECE)
1131	Squarylium	888
1137	Squarylium	970 (TECE)
1138	Squarylium	1010



1139	Fluorene	455/965 (MeOH)
1140	Fluorene	455/965 (TECE)
1141	Fluorene	725 (Ac)
1145	Fluorene	500/1360 (Ac)
1148	Fluorene	980 (Ac)
1149	Squarylium	687
1150	Squarylium	880
1151	Croconium	850
1152	Fluorene	900, 1040 (Ac)
1153	Fluorene	1000 (Ac)
1155	Squarylium	980 (TECE) (LOW CONC.) 1060 (TECE) (HIGH CONC.)
1156	Squarylium	960(TECE)
1157	Squarylium	890
1159	Squarylium	980 (TECE)
1160	Squarylium	605, 815
1161	Methine	335, 767
1166	Squarylium	770
1168	Squarylium	910
1169	Ni Complex	790 (DMSO)
1170	Cu Complex	775
1171	Ni Complex	779
1172	Cu Complex	759
1173	Ni Complex	768
1175	Squarylium	668/796
1177	Methine	754
1178	Methine	728

**FOOTNOTE:**

$\lambda_{max}$  values obtained in methylene chloride unless otherwise specified:

- (TECE) = 1,1,2,2, tetrachloroethane
- (DMF) = dimethylformamide
- (MeOH) = methanol
- (DMSO) = dimethylsulfoxide
- (Ac) = acetone

**B. INCORPORATION OF DYES INTO PLASTIC**

In this program, a number of candidate NIR laser-protective dyes were evaluated in plastic media. These dyes are listed in Table 2.

**Table 2**  
**Dye/Plastic Combinations Investigated during this Program**

DYE	PLASTIC*	$\lambda_{max}$ (nm)
SS-1044	PETG	834
	PC	---
SS-1045	PC	777
SS-1049	PETG	1070
	PC	---
SS-1101	PMMA	850/990
SS-1106	PC	717
SS-1106/SS-1045	PC	700-800
SS-1107	PETG	1070
	PC	---
SS-1116	PETG	905
	PC	905
SS-1118	PETG	985
	PC	975
SS-1145	PETG	---
SS-1150	PETG	893
	PC	---
SS-1151	PC	860
SS-1155	PETG	1060
	PC	---
SS-1159	PC	980
SS-1161	PC	755

\* PETG-Polyethylene terphthalate glycolate, PC-Polycarbonate,  
PMMA-polymethyl methacrylate

## **B-1 Testing Methodology**

In the early part of this program, dyes were incorporated into plastic through solution casting. That is, the plastic and dye were co-dissolved in a suitable medium, such as methylene chloride. The resulting solution was then spread in a thin layer on a glass plate. The volatile solvent was allowed to evaporate, leaving a thin sheet of dye-impregnated plastic for testing. The obvious disadvantage of this approach is that commercial extrusion or injection-molding processes expose the dye to elevated temperatures and shear for a period of minutes, and this is absent from the solution casting.

The next stage of testing involved construction of a "hot-melt" apparatus, in which molten plastic and dye are thoroughly mixed with a time-temperature profile (200°-300° C for a period of 2-3 minutes) approximating that for commercial processing. This led to a more realistic assessment of the performance of our NIR dyes. Even this approach is idealized in that it does not include the shear (and the associated local heating problems) of extrusion or injection-molding. It does have the advantage of allowing real-time, in-house testing of new dyes. The compounded material was then pressed into thin wafers for spectral analysis.

Dyes that performed well in the hot-melt apparatus were then impregnated into plastic using an outside extruder or injection-molder. Time-temperature profiles in these machines were selected to closely match the conditions for producing commercial lens blanks. Sometimes special processing conditions were needed to produce good dye performance; these are described in the sections below for each dye.

## **B-2 Dyes Developed for 1064 nm ( $\lambda_3$ )**

Because of the importance of this wavelength for industrial, medical, and military applications, we will discuss  $\lambda_3$  absorbers first. During this program, Spectra Science developed three dyes for 1064 nm: SS-1049, SS-1107, and SS-1155. The last of these was synthesized

relatively late in the program, and so is less well studied. All are characterized by a neutral-gray appearance in lens blanks, which is an advantage over the conventional green  $\lambda_3$  dye in some areas (e.g., color-balancing).

Early work on SS-1107 and SS-1049 yielded relatively low photopic values in PC (approximately 16-18% for an OD of four). A major breakthrough occurred when molecular oxygen was removed from both the plastic pellets and the atmosphere in the extruder/injection molder. The first time this was implemented, the photopic values jumped to the 25-27% level in PC (for an OD = 4). A detailed study of the effect of oxygen was presented in the October, 1992 Report. By being more scrupulous in the removal of oxygen and by minimizing the processing temperature of the PC, photopic values were further improved to about 35 - 37% (OD = 4).

The results from a series of extrusion tests performed on SS-1107 and SS-1049 in both PC and PETG are included in Table 3.

**Table 3**  
**Photopic/Scotopic Transmission**  
**Extrapolated to IR Absorbance = 4.0**

Plastic	SS-1107		SS-1049	
	Photopic	Scotopic	Photopic	Scotopic
PC	33.2	39.1	24.5	22.8
PETG	40.6	44.9	40.2	39.0

The next step was to demonstrate that comparable performance could be achieved by a *commercial* injection-molder using conventional equipment. To this end, four lots of lenses were injection-molded with SS-1107 in PC at Bollé in France. The targeted absorbance was 6.0. Photopic/scotopic measurements made directly on the lenses showed numbers very similar to those achieved at Spectra Science.

A lens sample containing SS-1107 was forwarded to J. Lund of the U.S. Army for laser saturation tests. Subsequent measurements in his laboratory verified that this dye passes saturation requirements for laser eye protection. This result, together with the photopic/scotopic performance, demonstrates the suitability of this material for commercial production of polycarbonate lenses.

Finally, a number of lenses containing two and three Spectra Science dyes were fabricated at Bollé to characterize optical performance with multiple-line protection. Specifically, lenses were molded to protect against laser wavelengths: (a)  $\lambda_3$ , (b)  $\lambda_3 + \lambda_2$ , and (c)  $\lambda_3 + \lambda_2 + \lambda_1$ . The lenses were prepared by injection-molding vacuum-deoxygenated polycarbonate pellets that had been coated with the following dyes:

$\lambda_1$ : SS-1037,       $\lambda_2$ : SS-1093,       $\lambda_3$ : SS-1107

The spectral and photopic properties of these experimental lenses are presented in Table 4.

**Table 4**  
**Optical Performance of Lenses Containing Dyes and Dye Mixtures**  
**Capable of Protecting Against Various Laser Wavelengths**

<u>Lens</u>	<u>TARGET ABSORBANCE</u>			<u>Measured Photopic Visual % transmission</u>
	<u>1064</u>	<u>694</u>	<u>532</u>	
$\lambda_3$	4	—	—	34.9
$\lambda_3 + \lambda_2$	4	4	—	25.8
$\lambda_3 + \lambda_2 + \lambda_1$	4	4	2	9.3

Samples of each of these dyes systems will be provided to the Army at the end of the program.

In the February, 1993 monthly, we reported the synthesis of a new squaric acid dye (SS-1155) absorbing at 1060 nm ( $\lambda_3$ ) in TECE.

Shortly thereafter, this compound was evaluated in both PC and

PETG. Results are given in Table 5. Table 6 shows the effects of additives on the spectra of three identical samples (40 mg SS-1155 / 1/2 lb PETG). Since we had seen significant changes in the spectral profile of liquid solutions when we added either of the starting materials (squaric acid or end groups) to the SS-1155 dye solution, we wanted to explore their effects in extruded plastic. While we did not observe spectral shifts of any note, the maximum absorbance changed as listed in Table 6. The results to date for this dye have not been as good as those for SS-1107, although it has not been studied as extensively due to its synthesis late in the program.

**Table 5**  
**Extrusion Results for SS-1155 in Plastic**

<u>PLASTIC</u>	<u><math>\lambda_{max}</math></u>	<u>PHOTOPIC</u>	<u>SCOTOPIC</u>
Polycarbonate	1064	29.0	27.1
PETG	1064	37.7	36.6

**Table 6**  
**Effect of Additives on the Absorption of SS-1155 in PETG**

<u>ADDITIVE</u>	<u>AMOUNT</u>	<u><math>\lambda_{max}</math></u>	<u><math>I_{max}</math></u>
None	NA	1065	0.67
Squaric Acid	40 mg	1065	0.84
Squaric Acid	10 mg	1065	0.84
+ Endgroup	40 mg		

### **B-3 Dyes to Cover the 700-800 nm Region (Alexandrite)**

In order to determine mutual compatibility and broad-band absorption capabilities of Spectra Science NIR dyes, SS-1106 and SS-1045 were co-processed into GE High-Flow polycarbonate resin. Individually, these two dyes have peak absorptions ( $\lambda_{max}$ ) at 717 and 777 nm, respectively. These particular dyes were chosen because, together, they cover the tuning range of the Alexandrite laser (700 to 800 nm), which is finding increased use in both military and commercial applications and environments.

Initially, several dye-doped wafer samples were prepared using the thermoplastic polymer mixing apparatus described in the September 1992 report. The mixing conditions were approximately two and one half minutes at 215° to 225°C. These mixing conditions were chosen to simulate those encountered in the commercial injection-molding of PC lenses. The compounded SS-1106 and SS-1045 dye containing PC resin was then pressed into a 0.14 mm thick film by heating the resin between chrome plates (in a hot press) for approximately one and one half minutes at 190°C. The absorption spectrum of this wafer showed an optical density of 1.0-1.5 in the 700 to 800 nm wavelength range. This extrapolates to about 15 for a 2-mm thick lens. Clearly, the concentrations used in this experiment are much higher than that needed for a typical military laser-protective lens application (OD approximately 4 to 6).

After successful extrusion tests of this dye combination, we went on to the injection-molding of lens blanks. By this time, we had to arrange for another commercial vendor to injection-mold the pieces. (Our previous vendor, Bollé of France, was unavailable for trials.) The resulting lens blanks were of high quality with good dye performance (i.e., no evidence of dye degradation). The optical densities were considerably higher than anticipated, because the lenses are 3.1 mm thick, rather than the 2 mm we expected. The estimated absorbance for these pieces is 16.5 for the SS-1045 peak (776 nm), and 13.2 near the SS-1106 peak (734 nm). These values are extrapolated from thin wafers pressed from the thick lens blanks. (The absorption spectrum of one such wafer is included as Figure 2.)

Overall, Figure 2 represents a promising materials development. Noteworthy is the high optical transmission in the visible range. The ratio of peak absorbance in the IR to that for 550 nm is 25 to 30, indicating these photopic values should be very attractive for lenses utilizing these dyes. Furthermore, by adjusting the relative concentration of the two dye components, the absorption profile in the 700 to 800 nm range can be rendered quite flat.

#### **B-4 Dyes for 800-900 nm Absorption**

In this spectral region, three dyes were successfully extruded into PETG and/or PC:

- (a.) the croconium dye SS-1044 ( $\lambda_{\max} = 834$  nm in PETG).
- (b.) the squarylium dye SS-1151 ( $\lambda_{\max} = 860$  nm in PC).
- (c.) the squarylium dye SS-1150 ( $\lambda_{\max} = 893$  nm in PETG).

(As discussed in Section B-2, deoxygenated resin was used.) The absorption spectra of SS-1150 in PETG and SS-1151 in PC are shown in Figures 3 and 4, respectively. Note in particular the high visible transmission of these samples. The strong peak at 893 nm for SS-1150 is very close to the emission of a semiconductor laser at approximately 900 nm. Similarly, the absorption peak for SS-1151 covers the 850 nm emission of another semiconductor device.

SS-1044 and SS-1150 were also tested in PC. SS-1150 performed very well, with a strong absorption peak at approximately 900 nm, and low visible absorption. (The spectrum is very similar to that shown in Figure 3.) The estimated photopic transmission for an OD = 4 is approximately 45%.

For SS-1044 in PC, on the other hand, the results were not so favorable. Apparently, much of the dye degraded during the extrusion process.

#### **B-5 Dyes for 900 - 1000 nm Absorption**

For this spectral region, new dyes synthesized in this program include SS-1116 (905 nm in PC), SS-1118 (975 nm in PC), SS-1101 (with peaks at 850 and 990 nm in PMMA), and SS-1159 (980 nm in PC). Of these, SS-1101 and SS-1159 are particularly promising in that they show good visible transmission in PC and provide relatively broad coverage from about 850 - 1050 nm. Potential laser applications include protection against Ti:sapphire, which is tunable from 800 to 1000 nm.



The absorption spectrum of SS-1159 extruded into PC is shown in Figure 5. Deoxygenated resin was used to maximize photopic performance. The ratio of peak IR absorbance to absorbance at 550 nm is approximately 12 for this dye, which makes it an attractive candidate for this spectral region. In July, samples of both SS-1159 and SS-1101 were prepared for outside injection-molding trials. The results are not available at this time.

#### **B-6 Dyes for Wavelengths beyond 1200 nm**

Our best candidate for longer wavelengths in the NIR was the fluorene dye SS-1145. As discussed in the Sixth Quarterly Report, Spectra Science has synthesized a number of new fluorene compounds covering the 750-1400 nm region. These dyes proved difficult to make in high yield, and most have relatively low decomposition temperatures (<250 °C). One dye however, SS-1145, has a peak absorption at 1360 nm (in acetone) and a decomposition temperature >300 °C. This compound was prepared in sufficient quantity (60 mg) for extrusion tests using deoxygenated resin. The resulting material, however, showed little absorption anywhere in the NIR, indicating that little of the fluorene dye survived the extrusion process.

### **SECTION III - ADMINISTRATIVE COMMENTS**

During this Phase II SBIR project, Spectra Science succeeded in synthesizing over 50 new dyes that have a  $\lambda_{\max}$  between 700 and 1400 nm. Emphasis was placed on creating stable, "notch" absorbers having minimum optical activity in the visible. By using these dyes in combination, an extended spectral range can be covered.

In making these compounds, new synthetic routes had to be developed. In the vast majority of cases, the dyes can be made reproducibly and in commercially useful quantities (tens of grams or larger). This synthetic activity represented a major effort, as numerous problems were encountered and had to be solved.


One of the dyes synthesized for 1064 nm, SS-1107, has been shown to be injection-moldable into PC with excellent transmission properties. (Photopic values of 35% and higher have been achieved at an OD = 4.) Because the absorption spectrum of this dye has a minimum near 480 nm, scotopic values are several percent higher, which is important for some military applications. Lens blanks produced using this dye have a neutral-gray appearance, which is an advantage over the conventional green lenses in many cases. SS-1107 has passed laser saturation tests performed by the Army.

A number of other dyes synthesized during this program have been molded or extruded into PC and/or PETG to cover specific wavelengths in the 700 -1100 nm range. In most cases, they can be used in various combinations to provide broad-band spectral coverage. The absorption properties of these dyes are detailed in Sections B-3 through B-6 of this report.


Finally, Spectra Science is in the process of arranging a strategic partnership with a commercial vendor to manufacture and market a full line of laser-protective eyewear. This line includes a number of NIR absorptive dyes developed during this program.

**Figure 1**  
**Chemical Structure of Spectra Science Laser Protective Dyes Listed in Table 1**


SS-1044\*




SS-1100




SS-1045




SS-1101




SS-1049




SS-1107




SS-1096




SS-1109




SS-1097




SS-1112




SS-1098




SS-1115




SS-1099\*




SS-1116















• where




is






**Figure 1 (cont.)**  
**Chemical Structure of Spectra Science Laser Protective Dyes Listed in Table 1**


SS-1140




SS-1141




SS-1145




SS-1148




SS-1149




SS-1150




SS-1151




SS-1152




SS-1153




SS-1155




SS-1156




SS-1157




SS-1159



SS-1160




SS-1161




**Figure 1 (cont.)**  
**Chemical Structure of Spectra Science Laser Protective Dyes Listed in Table 1**


SS-1166




SS-1168



SS-1169




SS-1170 through  
SS-1173




R = Me, Et  
M = Cu, Ni


SS-1175



SS-1177



SS-1178






**SPECTRA SCIENCE**

From: Dr. Dennis P. Pacheco

**Figure 2**

Spectra Science Broad-Band Absorber for the Alexandrite Laser  
(Spectrum is in Polycarbonate.)



**SPECTRA SCIENCE**

From: Dr. Dennis P. Pacheco

**FIGURE 3**

**ABSORPTION SPECTRUM OF THE SQUARYLIUM DYE SP-1150 EXTRUDED INTO PETG FILM**





Figure 4 Absorption Spectrum of the Squarylium Dye SS-1151 in PC.  
The peak absorption is at approximately 860 nm.

Absorbance



Wavelength

